

DECKARD'S DREAM MENU STRUCTURE REV 1.0

PNL (PANEL MODE)

PREV (selects patch 128 in factory bank)
NEXT (selects patch 1 in factory bank)
SAVE (prompts to save to patch # in user bank 1)
LOAD (prompts to load patch # in user bank 1)

(Press and hold Shift to select the following menus):

BNK1 (USER BANK 1)

PREV
NEXT
SAVE
LOAD

BNK2 (USER BANK 2)

PREV
NEXT
SAVE
LOAD

FCTRY (FACTORY BANK)

PREV
NEXT
LOAD

STNG (SETTINGS)

(* = Factory Default)

RETUNE

TO START RETUNE PRESS ENTER

MIDI

MODE

CHANNEL PRESSURE
POLY PRESSURE* (P.A.)
MPE

CHANNEL

1* (1 – 16)

CC RECEIVE

OFF*
ON

MOD WHEEL DESTINATION

LFO SPEED
LFO DEPTH – VCO*
LFO DEPTH - VCF
LFO DEPTH - VCA
BRILLIANCE
PORTAMENTO LEVEL
PWM SPEED 1
PWM SPEED 2
PWM SPEED 1+2
DETUNE
FEET 1
FEET 2

MODWHEEL POLARITY

POSITIVE*
NEGATIVE

CV

0-5V (0-1V TO 0-10V, ±1V INCREMENTS)

VOICE

MODE

MONOPHONIC
POLYFONIC*
UNISSON

DECKARD'S DREAM MENU STRUCTURE REV 1.0

NUMBER OF VOICES
8* (1 – 8)

DETUNE
0.0HZ* (0.0 – 3.0HZ, ±0.1HZ)

PLAYBACK
SUSTAIN I*
SUSTAIN II

TIME
LFO MAX
25.0HZ* (10.0 – 45.0HZ, ±1.0HZ)

LFO MIN
0.3HZ* (0.1 – 5.0HZ, ±0.1 HZ)

PWM MAX
70.0HZ* (10.0 – 100.0HZ, ±1 HZ)

PWM MIN
0.7HZ* (0.1 – 5.0HZ, ±0.1 HZ)

ATTACK TIME
20.0S* (1.0 – 9.0S ±1S, 10 – 100S ±10S)

DEC/REL TIME
15.0*S (15.0 – 150.0S, ±1S)

LFO DEPTH
CLASSIC*
EXTENDED

RESET TO DEFAULTS
TO RESET TO FACTORY DEFAULTS PRESS ENTER

USB MODE
HOST
DEVICE*

KEYBOARD
PITCHBAND RANGE
1 SEMITONES* (1 – 99, ±1 SEMITONES)

TRACKING WIDTH
2 OCT* (1 – 10 OCTAVES)

MIDDLE OCTAVE
6* (1 – 10)

PRESET VOLUME
+6 DB* (-6 TO +6 DB, ±1 DB)

EXPANSION
CHAIN
OFF*
ON

MODE
MASTER*
SLAVE

CALIBRATION
SLIDERS
SET CENTER DETTENT SLIDERS TO MIDDLE AND PRESS ENTER

OSCILLATORS
TO START AUTOTUNE PRESS ENTER

MICROTUNING
OFF*
ON

DEBUG
NEXT, PREV (DISPLAYS ALL SLIDER AND SWITCH VALUES)

FAN
ON*
OFF

ABOUT
COPYRIGHT INFORMATION

RESET SETTINGS
TO RESET SETTINGS PRESS ENTER