

Oakley Sound Systems

5U Oakley Modular Series

ADSR/VCA

Looping Envelope Generator

PCB Issues 3 and 4

Builder's Guide

V4.0.04

Tony Allgood B.Eng
Oakley Sound Systems
CARLISLE
United Kingdom



The updated 1U wide front panel in our traditional MOTM compatible format.

Introduction

This is the Project Builder's Guide for the issues 3 and 4 of the ADSR/VCA 5U module from Oakley Sound.

This document contains a basic introduction to the board, a full parts list for the components needed to populate the boards, and a list of the various interconnections.

Issue 3 and issue 4 PCBs are identical in everything but a slight change in tracking. Issue 4 boards improve grounding layout and allow the LED to be wired direct to its pad without any increased control voltage bleedthrough. The LED when fitted to an issue 3 board should be wired as detailed in the relevant section of this Builder's Guide.

For the User Manual, which contains an overview of the operation of the unit and all the calibration procedures, please visit the main project webpage at:

<http://www.oakleysound.com/adsr.htm>

For general information regarding where to get parts and suggested part numbers please see our useful Parts Guide at the project webpage or <http://www.oakleysound.com/parts.pdf>.

For general information on how to build our modules, including circuit board population, mounting front panel components and making up board interconnects please see our generic Construction Guide at the project webpage or <http://www.oakleysound.com/construct.pdf>.

The VC-ADSR/VCA PCB



The issue 4 VC-ADSR/VCA board mounted behind a natural finish Schaeffer panel. Note the use of the optional Sock4 board to mount the jack sockets. Note also the two 0.1" KK headers on the lower right. These headers can be attached to the 1U Upgrade module to allow for full voltage control of the modules four parameters.

I have provided space for the four main control pots on the PCB. If you use the specified 16mm Alpha pots and matching brackets, the PCB can be held firmly to the panel without any additional mounting procedures. The pot spacing is 1.625" and is the same as the vertical spacing on the MOTM modular synthesiser and most of our other modules.

The design requires plus and minus 15V supplies. The power supply should be adequately regulated. The current consumption is, with the LED on full, +45 mA and -25mA. Power is routed onto the PCB by a four way 0.156" MTA156 type connector or the special five way Synthesizers.com MTA100 header. You could, of course, wire up the board by soldering on wires directly. The four pins of the four way connector are +15V, ground, earth/panel ground, -15V. The earth/panel connection allows you to connect the metal front panel to the power supply's ground without it sharing the modules' ground line. More about this later.

The PCB has four mounting holes for M3 bolts, one near each corner. These are not required if you are using the three 16mm pot brackets. The board size is 143mm (high) x 87mm (deep).

Note that although the module is called ADSR/VCA the PCB used in this project is the VC-ADSR board. This is because the design features an internal voltage controlled core. In conjunction with our Upgrade board the VC-ADSR board can be made into a double width module called the VC-ADSR.

The board has been laid out to accept connection to our Sock4 socket board. This small board speeds up the wiring of the four sockets and reduces the chances of mistakes.

Issue 3 and 4 ADSR/VCA Parts List

For general information regarding where to get parts and suggested part numbers please see our useful Parts Guide at the project webpage or <http://www.oakleysound.com/parts.pdf>.

The components are grouped into values, the order of the component names is of no particular consequence.

A quick note on European part descriptions. R is shorthand for ohm. K is shorthand for kilo-ohm. R is shorthand for ohm. So 22R is 22 ohm, 1K5 is 1,500 ohms or 1.5 kilohms. For capacitors: 1uF = one microfarad = 1000nF = one thousand nanofarad.

To prevent loss of the small '.' as the decimal point, a convention of inserting the unit in its place is used. eg. 4R7 is a 4.7 ohm, 4K7 is a 4700 ohm resistor, 6n8 is a 6.8 nF capacitor.

This board may also be used with our older simpler front panel design. However, there are small differences to the board components used for each option.

Resistors

Resistors 1/4W, 5% or better

100R	R47, R37
820R	R10
1K	R49
2K2	R40, R42, R2
4K7	R14, R53, R54
5K1	R51, R59, R3
10K	R8, R50, R16, R19, R11, R38, R20, R17
12K	R5, R44, R56, R45, R46, R6
22K	R41
33K	R29
36K	R35
47K	R57, R13, R31, R21, R22, R26, R9, R4, R7
62K	R30
100K	R28, R32, R39, R12, R1, R58, R33, R55
390K	R23, R24
1M	R52, R48
3M3	R18, R15, R43

Options depending on front panel design:

1. New panel design with two switches. If building this version then also fit the following parts:

1K	R34
22K	R36

Do not fit R25 & R27.

2. Old panel design. This included the inverted shaped ADSR output but did not have the looping facility or range switch. If you are building this then you need to fit the following parts:

1K	R25
47K	R27

Do not fit R34 & R36.

Capacitors

33pF 5mm low-K ceramic	C16
100pF 5mm low-K ceramic	C11
470pF 5mm low-K ceramic	C7
100nF axial multilayer ceramic	C18, C8, C10, C15, C6, C5, C1, C3, C4, C9, C20, C2
1nF, 100V polyester box 5mm	C13, C14
220nF, 63V polyester box 5mm	C12
1uF, 63V polyester box 5mm	C17
2u2, 63V electrolytic	C21, C19

Discrete Semiconductors

1N4148 silicon signal diode	D2, D5, D6, D7, D10
8V2 zener diode	D1
BAT42 Schottky diode	D4, D3
BC550 NPN transistor	Q1, Q2, Q3, Q4
BC560 PNP transistor	Q5
LED 5mm green bipolar	LED - Mounted off board via flying wires.

Options depending on front panel design:

1. New panel design with two switches. If building this version then also fit the following parts:

1N4148 silicon signal diode	D8, D9
-----------------------------	--------

2. Old panel design. This included the inverted shaped ADSR output but did not have the looping facility or range switch. If you are building this then do not fit D8 nor D9.

Integrated Circuit Semiconductors

LM13700 dual OTA	U7
4001 Quad NOR gate	U1
4052 DP4T analogue switch	U2
THAT2180LC audio VCA	U8
TL072 dual FET op-amp	U4, U5, U6
TL074 quad FET op-amp	U3

IC sockets can also be used. You need two 16 pin DIL sockets, two 14 pin DIL sockets, and three 8 pin DIL sockets.

Pots

All pots 16mm Alpha or equivalent.

47K or 50K linear	ATTACK, DECAY, RELEASE
10K linear	SUSTAIN
Alpha pot brackets	3 off

Trimmers

100K 6mm horizontal	OFF
20K 6mm horizontal	GAIN

Switches (for new panel design only)

SPDT, on-on	RNG	- to be connected via twisted pair
SPDT, on-off-on	MODE	- to be connected with single core wire

Miscellaneous

Leaded axial ferrite beads	L1, L2	
MTA156 4 way header	PSU	- Oakley/MOTM power supply
MTA100 6-way header	PWR	- Synthesizers.com power supply
Molex/MTA 0.1" header 3-way	BUSS	- for connecting to the Oakley Buss
Molex/MTA 0.1" header 8-way	I/O	- for connecting to sockets
Molex/MTA 0.1" housing 8-way	I/O	- for connecting to sockets
Molex/MTA 0.1" header 4-way	A-D, S-R	- to make the VC-ADSR option.
0.1" jumpers	For fitting to A-D and S-R headers.	
Molex/MTA 0.1" housing 2-way	LED	- optional connecting technique for the LED.

5mm green LED lens	LED
5mm LED lens securing ring	LED (if lens is not self securing)
Switchcraft 112APC 1/4" sockets	Four off mounted either on the Sock4 board or on panel
Four knobs	
Around 2m of insulated multistrand hook up wire.	


Additional components required if using optional Sock4 board

Molex/MTA 0.1" header 8-way	I/O
Molex/MTA 0.1" housing 8-way	I/O
112APC Switchcraft 1/4" socket	SK1, SK2, SK3, SK4

A single wire link is to be fitted to L1 on the Sock4 PCB.

If using Molex KK you'll also need at least 16 crimp terminals.


Suitable lengths of wire to make up the single 100mm interconnect and two cable ties.



Using Molex KK 0.1" housings and crimps makes connecting to the LED very simple. The LED clip used here is a 5mm low profile clear type with a white plastic securing ring. The actual LED is a green LED in a water clear package. This is an issue 4 board, the earlier issue 3 boards require the cathode connection to be taken back to the power supply header – see later for more details.

Other Notes

For those who have fitted the A-D and S-R 0.1" headers, but are not intending to upgrade to the full VC-ADSR module set immediately, you will need to use those little jumpers. These fit across each pair of pins on the headers, that is pin1/2 and pin3/4.



Four sets of jumpers fitted to two Molex KK headers. This module can now be either expanded to make the VC-ADSR module set, or simply left like this for ordinary ADSR usage.

If you are not intending to ever upgrade your module, then before you can use the module **you must short out the headers**. With four small pieces of uninsulated wire, resistor clippings are fine, you will need to short out the four pairs of pins on both headers. Each header must have the following pins shorted together, pins 1 and 2, and then pins 3 and 4. Pin 1 is depicted by the square pin.

Connections

Power connections – MOTM and Oakley

The PSU power socket is 0.156” Molex/MTA 4-way header. Friction lock types are recommended. This system is compatible with MOTM systems.

<i>Power</i>	<i>Pin number</i>
+15V	1
Module GND	2
Earth/PAN	3
-15V	4

Pin 1 on the I/O header has been provided to allow the ground tags of the jack sockets to be connected to the powers supply ground without using the module’s 0V supply. Earth loops cannot occur through patch leads this way, although screening is maintained. Of course, this can only work if all your modules follow this principle.

Power connections – Synthesizers.com

The PWR power socket is to be fitted if you are using the module with a Synthesizers.com system. In this case you should not fit the PSU header. The PWR header is a six way 0.1” MTA, but with the pin that is in location 2 removed. In this way location 3 is actually pin 2 on my schematic, location 4 is actually pin 5 and so on.

<i>Power</i>	<i>Location number</i>	<i>Schematic Pin number</i>
+15V	1	1
Missing Pin	2	
+5V	3	2
Module GND	4	3
-15V	5	4
Not connected	6	5

+5V is not used on this module, so location 3 (pin 2) is not actually connected to anything on the PCB.


If fitting the PWR header, you will also need to link out pins 2 and 3 of PSU. This connects the panel ground with the module ground. Simply solder a solid wire hoop made from a resistor lead clipping to join the middle two pads of PSU together.

Building the ADSR module using the Sock4 board

This is the simplest way of connecting all the sockets to the main board. The Sock4 board should be populated in the way described in our construction guide found on the project webpage. There is only one eight way header and it is to be fitted to the bottom side of the board. Don't forget to solder in the wire link L1. Link L2 is left open.

You need to make up only one eight way interconnect. It should be made so that it is 100mm long.

The Sock 4 is really designed to go with our new panel layout. However, if you wish to use it with our older layout then your interconnect needs to be wired slightly differently. You need to ensure that pins 2 and 6 are swapped. That is, pin 2 on the main board side needs to go to pin 6 on the socket board., and pin 6 on the main board side needs to go to pin 2 on the socket board.




The prototype unit showing the detail of the board to board interconnect. Here I have used the Molex KK 0.1" system to connect the Sock4 to the main PCB.

Hand wiring the sockets

If you have bought Switchcraft 112A sockets you will see that they have three connections. One is the earth or ground tag. One is the signal tag which will be connected to the tip of the jack plug when it is inserted. The third tag is the normalised tag, or NC (normally closed) tag. The NC tag is internally connected to the signal tag when a jack is not connected. This connection is automatically broken when you insert a jack.

Once fitted to the front panel the ground tags of each socket can be all connected together with solid wire. I use 0.91mm diameter tinned copper wire for this job. It is nice and stiff, so retains its shape. A single piece of insulated wire can then be used to connect those connected earth tags to pin 1 of I/O. Pin 1 is the square solder pad.



A close up of the solid core wire frame that joins the earth lugs together. A single wire, lower left, goes back to pin 1 on the I/O header on the PCB. I have used Switchcraft 112APC sockets.

All the other connections are connected to the signal or NC lugs of the sockets. The tables below show the connections you need to make:

New front panel layout

<i>Pin</i>	<i>Pad name</i>	<i>Socket Connection</i>	<i>Lug Type</i>
Pin 1	PANEL_GND	Connect to all sockets	Earth lugs
Pin 2	ADSR+	Connect to VCA OUT	Signal lug
Pin 3	NC	No connection	
Pin 4	CV_IN	Connect to VCA IN	Signal lug
Pin 5	CV_NC	Connect to VCA IN	NC lug
Pin 6	ADSR_ADSR-	Connect to ADSR	Signal lug
Pin 7	GATE_BUSS	Connect to GATE	NC lug
Pin 8	GATE_IN	Connect to GATE	Signal lug

Old front panel layout

<i>Pin</i>	<i>Pad name</i>	<i>Socket Connection</i>	<i>Lug Type</i>
Pin 1	PANEL_GND	Connect to all sockets	Earth lugs
Pin 2	ADSR+	Connect to OUT+	Signal lug
Pin 3	NC	No connection	
Pin 4	CV_IN	Connect to IN	Signal lug
Pin 5	CV_NC	Connect to IN	NC lug
Pin 6	ADSR_ADSR-	Connect to OUT-	Signal lug
Pin 7	GATE_BUSS	Connect to GATE	NC lug
Pin 8	GATE_IN	Connect to GATE	Signal lug




This older style panel fitted to an issue 3 PCB has used hand wired sockets.

Wiring the LED

a) Issue 3 Boards Only

This should have been straightforward but on building the prototype I noticed that performance could be improved by wiring the LED slightly differently than intended. If you wire the LED to the pads marked LED then the considerable current taken by the LED produces a small perturbation on the output of the VCA. Since we should strive for the best I think it is wise to connect your LED as I have now done:

Wire the anode of your LED to pin 1 of the pad labelled LED. Pin 1 is the square pad. However, wire the cathode of the LED all the way back to the ground pads of the spare power supply header on the board. If you have used the MOTM/Oakley header, PSU, you can wire the cathode back to pin 3 of the dotcom PWR header. Pin 3 is the third one down – which is the fourth position of the header.



Issue 3: The black wire is the cathode connection and carries the ground connection to the LED. Notice I have used a Molex KK 0.1" header to neatly attach the connections to the LED.


If you have fitted the PWR header then you should connect the LED's cathode to the wire link that joins pins 2 and 3 of PSU together.

b) Issue 4 Boards Only

Wiring the LED is straightforward. Simply connect the LED to the pads directly below where the LED is mounted onto the front panel. The anode of the LED goes to the square pad and the cathode goes to the round pin.


Wiring the switches

The new panel design features two switches. Both are wired in slightly different fashions. The mode switch (on-off-on) is wired with three pieces of straight solid core wire as shown in the picture below:



The solid core wire is looped around each switch lug and soldered in place. The switch needs to be in its place and tightened before soldering the leads.

The range switch is wired with a twisted wire pair. This simply made by twisting two pieces of insulated multistrand wire together to form a simple cable. You can use two different colours but you don't have to. It does not matter which wire connects to which lug on the switch. All the range switch does is short out the connections when set to SLOW.



It is the top two lugs of the switch that connect to the two pads of RNG.

Testing, testing, 1, 2, 3...

Set the mode switch to NORM and the range switch to FAST. Connect +/-15V to the unit making sure you are applying the power correctly. Make sure that the LED is not lit. If it's on, switch off and check all the parts again thoroughly. If your LED is off, and there is no smoke rising from the board (yikes!!), you should quickly run your finger over all the ICs. Hopefully, none of them are getting too warm to touch. If they are there is a problem.

Click the switch in LOOP and the set the sustain pot to its minimum value. You may see the LED start to flash. Altering the attack value should change the rate at which the LED ramps to full brightness. Altering the decay will affect the time it takes to subside. At fast attack and decay times the LED will simply flicker indicating that the ADSR outputs are now moving very fast indeed. Change the range to SLOW and the LED should pulse at a slower rate. Very slow speeds should be obtainable at the slower settings of attack and decay.

Make sure the looping stops if you turn up the sustain past about 10% of full scale.

If nothing has happened so far do make sure you have the jumpers on, or wire links fitted to, the A-D and S-R headers.

Flip the mode switch back to NORM and use a gate signal from a midi-CV convertor or an LFO's square wave output. Turn all the pots to their minimum value. The LED should briefly blip on for every low to high gate transition. Increase the decay pot, and hopefully, the LED blips will get brighter and last longer.

Now increase the sustain pot. This should increase the LED brightness, and it should stay on for longer. It should now stay on for the time the gate is high.

Increase the attack time, you should notice the LED ramping up to full brightness.

Now connect an audio signal of some sort, any will do, but a simple triangle wave is quite sufficient. You should connect it to the VCA IN socket. Connect the VCA OUT to an input channel on your mixing desk or other audio input. Hopefully, you should find that when the ADSR is gated the audio is heard. Play with the A, D, S and R pots to make sure they do the usual things. If you are not familiar with their action, I suggest you read the section at the front of the User Manual.

Make sure that the ADSR socket also produces an output. This output is not shaped by the VCA IN signal and should be a standard envelope generator output of 0 to +5V. You can test it by routing it to a VCF or VCO.

Final Comments

If you have any problems with the module, an excellent source of support is the Oakley Sound Forum at Muffwiggler.com. Paul Darlow and I are on this group, as well as many other users and builders of Oakley modules.

If you can't get your project to work, then Oakley Sound Systems are able to offer a 'get you working' service. If you wish to take up this service please e-mail me, Tony Allgood, at my contact e-mail address found on the website. I can service either fully populated PCBs or whole modules. You will be charged for all postage costs, any parts used and my time at 25GBP per hour. Most faults can be found and fixed within one hour, and I normally return modules within a week. The minimum charge is 25GBP plus return postage costs.

If you have a comment about this builder's guide, or have found a mistake in it, then please do let me know. But please do not contact me or Paul Darlow directly with questions about sourcing components or general fault finding. Honestly, we would love to help but we do not have the time to help everyone individually by e-mail.

Last but not least, can I say a big thank you to all of you who helped and inspired me. Thanks especially to all those nice people on the Synth-diy and Analogue Heaven mailing lists and those at Muffwiggler.com.

Tony Allgood at Oakley Sound

Cumbria, UK
© November 2010

No part of this document may be copied by whatever means without my permission.